

## The Micro Wand product features & warranty information

This product comes with a 12 month manufacturers warranty. In order to qualify for your 12 month manufacturers warranty you must activate it by registering your product on line at [www.cloudninehair.com](http://www.cloudninehair.com) within 14 days from date of purchase. This does not affect your consumer rights.

Please read this section carefully before you use your new styling product. For full product information, styling hints, tips and to register your product or for helpdesk information, visit [www.cloudninehair.com](http://www.cloudninehair.com).



- 1 - Heat resistant guard
- 2 - Temperature indicator
- 3 - Power switch
- 4 - Ceramic barrel

## The Micro Wand product safety

Don't use your styling product near water.

Don't contaminate any part of your product with any chemical, hair colour or dye.

Don't use on wet hair.

If the wand is damaged in any way it must be repaired or replaced by our service centre or it's agent, do not use it, instead go to our website for help desk contact details.

Always unplug from the mains supply immediately after use.

Clean your product by gently wiping with a damp lint free cloth, do not use sprays or detergents.

Never immerse your product in water and always switch off and unplug from the mains power supply before cleaning.

### General wand safety

Your wand can get incredibly hot so you really must be careful when using it.

Do not touch the barrel when it is switched on.

Keep hairsprays and styling aids at a safe distance away from your wand.

Always wear the protective glove when using your wand on the hand which you use to wind the hair around the barrel of the wand.

### Safety features

Hibernation mode - The intelligent sleep technology within the wand will automatically work when the wand has been switched on but not used for a period of 30 minutes. Once in hibernation mode you'll notice that the temperature panel will occasionally flash a green light to remind you. However during this mode the actual wand will cool down. When you're ready to use your wand again simply switch it off and back on again

### Voltage

The Cloud Nine® Micro Wand can be operated with a mains voltage ranging from 220-240 Volts ac 50/60Hz, 30w.

### Operation Failure

If your styling product fails to work please follow this guide:

Check that your product and the power supply are switched on

If your product, cable or plug become damaged in any way stop using it immediately and return your product to our service centre for repair

Under no circumstances should you or anyone else tamper with the product as this will invalidate your warranty

### Remember

It's important that you never use your styling product for anything other than styling hair as directed in the quick start guide. Your product has been specifically designed for this purpose and using the product for any other purpose could be dangerous.

### User Advice

Please remember to keep your original proof of purchase in a safe place. This product benefits from a 12 month warranty, subject to terms and conditions.

This appliance can be used by persons aged from 16 years and above. If persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge use this product, an adult responsible for their safety must ensure that they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be carried out by children without supervision.

If the supply cord is damaged, it must be replaced by the manufacturer, or it's service agent in order to avoid a hazard.

Model No. C9-MW1.0



WARNING: Do not use this appliance near bathtubs, showers, basins or other vessels containing water.



This marking indicates that this product should not be disposed of with other household wastes. To prevent possible harm to the environment or human health from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources.

## Using the Micro Wand to create professional curls

- Remove the wand from its heat resistant guard by gripping the cover and pulling to release.
- Ensure that you wear the protective glove provided on the hand you will use to wind your hair round the wand.
- Plug into the mains power and turn on by pressing and holding the power button for two seconds.
- The power indicator will flash and then remain green once the LOW temperature is reached.
- To select the HIGH temperature, press the power switch again until the selected temperature flashes. The indicator will remain green once the temperature is reached. You can now begin styling your hair.
- Always use the wand on clean, dry hair.
- Should you require a lower temperature during styling, press the power button again until the low temperature indicator light flashes. Allow time for the wand to cool sufficiently – do not use until the indicator light remains green.
- Once you have finished styling, turn the power off by pressing the power button for two seconds until the green indicator light has gone off and unplug from the mains power supply.
- After use, replace the wand into its heat resistant guard.
- Never wrap the cord around the wand.

Also by Cloud Nine:

**The Standard and Wide Irons** by Cloud Nine® will help you create your perfect style. Smooth, flick, curl or straighten at a temperature to suit your hair type.

**The Micro Iron** by Cloud Nine® is perfect for shorter hair or styling on the move. Measuring just 6 inches long but with all the quality and technology you need.

**TheO** by Cloud Nine® creates volume in an instant. TheO rollers heat up in seconds and easily grip in place. All you have to do is decide how much volume you want.



**CLOUD NINE®**

UNIL C9 LTD  
PO BOX 302, ILKLEY, LS29 1ET, UK

[www.cloudninehair.com](http://www.cloudninehair.com)



**CLOUD NINE®**

*Style Infinity*

The Micro Wand - for professional curls

**Quick start  
and safety  
guide**